



Instructions


How to connect the keys



How to connect the Breakout Board



J4 Detail



J15 SOCD Enable/ Disable

You can change two different modes.

	Situation	Function
Enable	Short (New SOCD output)	Second command covers first command. Example: (← + → = →) (→ + ← = ←) (→ + ↓ = ↓)
Disable	NC (Current SOCD output)	Nothing (← + → = Nothing) (→ + ← = Nothing) (→ + ↓ = ↘)

How to change different modes


Automatically change the modes on different consoles

If you want to manually change PS3/PS4/PC modes, please follow the steps down below.

- Step 1
- Press and hold the button
1P=PS3, 2P=PS4, 3P=PC
- Step 2
- While pressing the button, connecting the fighting sticks to corresponding consoles.

How to connect the Brook Touch Pad

(optional purchase)



J2 Player LED Guide

● LED ON ○ LED OFF

Player	PS4	PS3	XInput
1P			
2P			
3P			
4P			
5P			
6P			
7P			



Product Info